

MCGRAW-EDISON


R5

7800-240-00-001

Power Systems Group
McGraw-Edison Company

412-~~777-3233~~

873-2100



R. Sherr: 11

McGraw-Edison

Power Systems Group
McGraw-Edison Company
Canonsburg, PA 15317

VACUUM CIRCUIT BREAKER
VAC-15.5KV-20KA-1200AMPERE
S. O. NO. C-03956-4
CONSOLIDATED ALUMINUM CORPORATION
LAKE CHARLES, LOUISIANA
P. O. NO. LCCP55569A
SERIAL NUMBER 26149

412-873-2390 - Ken MARRACCINO
STEVE - ENGINEER

ISSUE								DESCRIPTION	△	NUMBER	REV
8	7	6	5	4	3	2	1				
							IR A	BREAKER OUTLINE		SVB01920A	
							IR A	SCHEMATIC DIAGRAM		SHC03230A	
							IR A	MECHANISM WIRING DIAGRAM		SHC03231A	
								<u>PRINTED LITERATURE</u>			
							IR F	LEGEND DRAWING FOR ASSEMBLED SWITCHGEAR		SGA01186A	
							IR A	OE-12 C.T. EXCITING CURVES		IX-385575	
							IR A	OE-12 C.T. RATIO CURVES		RCF-385575	
							IR A	ELECTRICAL BILL OF MATERIAL		C-03956-4	
							IR	VAC-15.5-20 KA VACUUM BREAKER		S290-10-1	
							IR	VAC-15.5 VACUUM BREAKER (SUPPL. #1)		S290-10-1	
							IR	MO-1 OPERATING MECHANISM		S290-54-1	
							IR	MO-1 OPERATING MECHANISM (SUPPL. #1)		S290-54-1	
							IR	MO-1 OPERATING MECHANISM (SUPPL. #2)		S290-54-1	
							IR	"OE" BUSHING CURRENT TRANSFORMER		S290-80-2	
						4	3	CUSTOMER	A- APPROVAL	D- DELETED	
						2	2	SALES OFFICE	F- FOR REFERENCE ONLY		
						1	-	WITH BREAKER	I- INSTRUCTION BOOK		
									R- RECORD		
									McGRAW-EDISON Power Systems Division McGraw-Edison Company Canonsburg, PA 15317 USA		
									DWR GDY APPD <i>[Signature]</i>	DATE 2/82 DATE 3-5-82	CONFIDENTIAL MUST NOT BE USED IN ANY WAY DETRIMENTAL TO McGRAW-EDISON CO.
									MASTER DWG LIST		
									SHEET OF	C - 03956 - 4	REV
CONSOLIDATED ALUMINUM CORPORATION LAKE CHARLES, LOUISIANA P.O. NO. LCCP55569A VAC-15.5KV-20KA-1200AMPERE V.C.B.											


McGRAW-EDISON

**Power Systems Group
McGraw-Edison Company
Post Office Box 2850
Pittsburgh, PA 15230**

POWER CIRCUIT BREAKERS
 TYPE MO-1 OPERATING MECHANISM
 TRIP LATCH

SERVICE INFORMATION S290-54-1
 SUPPLEMENT 2
 JANUARY 1982

APPLICABLE FOR UNITS MANUFACTURED AFTER JULY 1981.



KV	LOAD		RESET MIN.	
	POUNDS	NEWTONS	POUNDS	NEWTONS
15	50-70	133-222	20	89
25.8	70-90	311-400	20	89
38	70-90	311-400	20	89

Figure 11
Trip latch adjustment.

- | | |
|---|-------------------------------------|
| 1. Metal strap or wire hooked around trip pin. | 5. 5/8" trip latch adjustment bolt. |
| 2. Spring scale--(10 to 100 lbs.)(45 to 450 newtons). | 6. Drive block. |
| 3. Trip pin. | 7. Trip link. |
| 4. Trip latch roller. | 8. Belleville washer. |

Power Circuit Breakers
Type MO-1 Operating Mechanism
Close Latch

Service Information S290-54-1
Supplement 1
April 1980

Applicable for units manufactured after February 1, 1980.

The stationary end of the close lever torsion spring is located at the underside of the close solenoid support plate as shown in Figure 9A.




Figure 9 A

Close coil armature air gap.

NOTE: With closing spring discharged, insert screwdriver and pull close latch to set position.

Power Circuit Breakers
Type VAC 15.5 kV
Vacuum Interrupter
Test During Installation

Service Information S290-10-1
Supplement 1
January 1980

After completing all electrical and mechanical connections for the Type VAC 15.5 kV vacuum breaker in accordance with the Installation Section of Service Information S290-10-1, electrically test and establish the vacuum by performing a simple a-c high voltage potential test on each interrupter.



RADIATION
WARNING

Refer to Vacuum Interrupter Test in the Maintenance Section of Service Information S290-10-1 for the proper procedure and observe all safety precautions during the tests to ensure personnel safety.

McGraw-Edison Company
Power Systems Division
Canonsburg, Pennsylvania 15317

NOTES:

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

5. Replace the new vacuum interrupter by performing steps 4A through 4F in reverse order leaving the stationary terminal clamping bolts loose.

NOTE: As a positioning check the connecting bar should penetrate the movable terminal clamp to within 15/16 inch (2.29 cm) (measured from the outside surface of the block to the stud of the vacuum interrupter).

- A. Tighten the movable terminal clamping bolts.
- B. Tighten the stationary terminal clamping bolts with the annular ring on the stationary stud positioned against the face of the stationary terminal clamp.

NOTE: For breakers with interrupters without annular rings, use of a 1/4 inch (6.35 mm) spacer between the edge of the vacuum interrupter and the block will yield proper positioning of the vacuum interrupter.

- C. Adjust open contact gap to 1/2 inch + 1/32 inch - 0 (12.7 mm + .8 mm - 0) by adjusting operating rod length at adjustment nut (Figure 4).

NOTE: In the open position the scribe mark is 1/2 inch (12.7 mm) further from the insulation guide than it is in the closed position.

6. Operate the breaker several times with the maintenance positioning wrench to insure proper alignment.

SPARE PARTS

Recommended spare parts stock should include one interrupter for each quantity of one to six breakers.

Description	Identification	Quantity Per Pole	Recommended Stock
Vacuum Interrupter	322061001	1	1
Bushing, 1200 Amp	SBB01090A	1	—
Bushing 2000 Amp	SBB01104A	1	—




Figure 15
Movable terminal (2000 ampere breaker).




Figure 16
Stationary terminal (2000 ampere breaker).




Figure 13
Movable terminal (1200 ampere breaker).




Figure 14
Stationary terminal (1200 ampere breaker).

6. Loosen four hex nuts and remove nuts, washers, and lockwashers fastening bushing flange to roof.
7. Carefully raise bushing slightly and support bushing flange. Remove bushing clamp.
8. Carefully remove bushing through roof.
9. Remove existing sealing material.
10. Clean painted surface of roof thoroughly.
11. Replace bushing clamp (do not tighten clamping bolts).
12. Reseal bushing flange to roof with "Ready Seal" rope provided with the replacement bushing. (Use Chemfluor Ready Seal with 3/32 inch bead.)
NOTE: Loop the "Ready Seal" rope around each of the four bushing studs by stringing the rope from stud to stud until a complete loop is formed on the bolt circle insuring a complete seal.
13. Lower the replacement bushing into place carefully.
NOTE: Be sure bottom of bushing passes through current transformer(s) and support, and flange is sealed properly.
14. Draw up the washers, lockwashers, and hex nuts on the bushing studs evenly.
15. Tighten the hex nuts in diagonally opposite pairs to insure proper bushing alignment.
16. Raise current transformer(s) and support into position.
17. Replace bolts and secure current transformer(s) and support.
NOTE: Be sure to check current transformer secondary leads.
18. Replace connector between the bushing clamp and the terminal assembly.
19. After aligning connector with terminal assembly and bushing clamp properly, tighten all bolts on the connector.
20. Tighten bolts on the bushing clamp.
21. Operate the breaker several times with the maintenance positioning wrench to insure proper alignment.

BUSHING CURRENT TRANSFORMERS

Refer to and follow Service Information S290-80-2 Type OE Bushing Current Transformer Instructions.

1. To replace a bushing current transformer, the breaker should be open, isolated from the system with the closing springs discharged.
2. Open both sides of the high-voltage compartment (Figure 3).
3. Cut the secondary leads near the current transformer(s) to be removed.
4. Follow steps 3 through 20 under Bushing in the Parts Replacement section. Refer to and follow Service Information S290-80-2, Type OE Bushing Current Transformer Instructions for:
 - A. Polarity marks.
 - B. Wiring and connections.
 - C. Short circuiting at the terminal blocks.

5. Operate the breaker several times with the maintenance positioning wrench to insure proper alignment.

VACUUM INTERRUPTERS

1. To replace a vacuum interrupter the breaker must be open, isolated from the system and the closing springs discharged.
2. Open both sides of the high-voltage compartment (Figure 3).
3. When interrupter contacts are new, the scribe mark (Figure 11) on the moving contact rod is approximately 1/8 inch (3.2 mm) above the insulation guide. When the scribe mark is even with the insulation guide, the interrupter must be replaced.
4. The vacuum interrupter is removed as follows:
 - A. At the stationary terminal, Figure 12, loosen the bolts and remove the connector between the bushing clamp and the terminal assembly (also see Figures 14 and 16).
 - B. Loosen the two clamping bolts securing the stationary terminal to the vacuum interrupter.
 - C. At the movable terminal clamp, remove the pin retaining the connecting link to the connecting bar on the vacuum interrupter (Figures 13 and 15).
NOTE: Relieve tension on connecting link by moving jackshaft toward closed position with maintenance positioning wrench (Figure 10).
 - D. Loosen two movable terminal clamping bolts, Figure 12.
NOTE: Inside clamping bolt may be difficult to reach due to laminations. Slide vacuum interrupter forward slightly.
NOTE: On 2000 ampere breakers also remove the side cooling fin (Figure 15).
 - E. Remove stationary clamp terminal by removing bolts at base.
 - F. Remove vacuum interrupter and stationary terminal clamp together being careful not to drop terminal clamp or interrupter.
 - G. Transfer the stationary terminal clamp to the replacement vacuum interrupter.

CAUTION

Be careful not to stress the bellows (Figure 11) coupling the movable contact to the body of the interrupter. Although life expectancy of the bellows is many times the rated life of the interrupter, external stresses, particularly torsional, can have a markedly deleterious effect on bellows life.

- H. Transfer the connecting bar and 1/2 inch lock-washer from the old interrupter to the replacement interrupter. Use a thin wrench to hold the interrupter stud while tightening; do not apply torque through the bellows to the interrupter.




Figure 12

Section of one pole of Type VAC 15.5 kv vacuum breaker showing assembly details.

Time Travel Test

1. Using the operating mechanism maintenance positioning wrench slow close the breaker (Figure 10).
2. Time travel device can be set up on the floor of the low-voltage compartment behind the mechanism.
3. Connect the time travel device directly to the crank provided on the jack shaft assembly (Figure 4).
4. Record direct readings of contact speed/motion characteristics.
5. Disconnect time travel device from crank on drive shaft.

PARTS REPLACEMENT

SAFETY PRECAUTION

Before replacing any part in a Type VAC-15.5 kv vacuum circuit breaker, the breaker must be out of service.

Refer to and follow instructions in S290-54-1 Type MO-1 Operating Mechanism prior to replacing any parts.

The operating mechanism maintenance positioning wrench can be used when replacing some parts. Observe all safety precautions in S290-54-1 as well as those throughout these instructions when replacing parts. Although the Type VAC breaker was designed with the safety of operating personnel foremost in mind, the inherent mechanical characteristics of the breaker along with the necessary activities of operating personnel make cautious work habits essential.

Refer to Spare Parts section for parts-ordering data.

Keep complete records of all parts replaced.

BUSHINGS

1. To replace a bushing, the breaker should be open, isolated from the system with the closing springs discharged.

NOTE: If any change in—or addition to—bushing current transformers is desired, make the change or addition at the same time the bushing is replaced.

2. Open both sides of the high-voltage compartment (Figure 3).
3. Referring to Figure 12, loosen bolts and remove the connector between the bushing clamp and the terminal assembly.
4. Loosen clamping bolts on the bushing clamp. (Do not attempt to remove bushing clamp at this time.)
5. Remove bolts holding current transformer in place and carefully lower support and current transformer(s) (Figure 12).

NOTE: Support and current transformer(s) should be held in this lowered position until bushing is removed. If any change in—or addition to—bushing current transformers is desired, change out after bushing removal and in accordance with instructions on current transformer replacement in this section.




Figure 11

Scribe mark on interrupter indicates extent of contact erosion. (Interrupter must be replaced if mark disappears when contacts are closed.)

Vacuum Interrupter Test (See Radiation Warning)

To electrically test and establish the integrity of the vacuum, each interrupter should be given a simple a-c high-voltage potential test. Breaker contacts must be in the open position. The vacuum condition is satisfactory provided the interrupter withstands 38 kv for one minute for a 15.5 kv breaker.

WARNING

Take care to insure that all panels and doors are secured during vacuum dielectric test.

NOTE: Before applying a-c voltage, wipe each interrupter with a clean, lint-free cloth.

1. Connect a high potential voltage source across the open interrupter contacts (a bushing-to-bushing connection is recommended for each phase). All other bushings are to be grounded.
2. Test voltage should be gradually increased to 38 kv (rms).
3. Maintain peak test voltage for one minute.
4. Test voltage should then be gradually decreased to zero.
5. If the vacuum interrupter fails the high potential test, replace the interrupter in accordance with the instructions in the Parts Replacement section.

NOTE: During high potential testing the outer metal shell of the vacuum interrupter can acquire an electrical charge which may be retained after the test voltage is removed. Before touching the interrupter, use a grounding stick to discharge the shell as well as other metal parts of the interrupter.



RADIATION WARNING

X-radiation can result when voltage in excess of rated maximum voltage is applied across the open-contact gap in a vacuum interrupter. Such radiation can become a health hazard on long exposure at close range. When performing high-voltage tests on vacuum interrupters, personnel safety can be insured by noting the following information and taking the necessary precautions.

1. American National Standard C37.09-1964 "A-C High-Voltage Circuit Breakers" allows tests after delivery which include application of 75 percent of rated low-frequency withstand voltage across open contact of the interrupters. This voltage (50-60 hertz) is tabulated below.
2. At test voltages listed in Columns C and D, radiation is negligible when interrupters are mounted in their respective operating structures, installed in their normal apparatus enclosure, with metal enclosure panels in place, and have contacts open to their recommended open-contact gap as listed in Column E.
3. Testing at voltages higher than those listed in Columns C and D may cause radiation emission injurious to personnel. If testing is to be performed at voltages above those listed in Columns C and D, additional radiation shielding is required.
4. Vacuum interrupter testing above 50 kv ac rms is not recommended.

CAUTION

5. If direct-current dielectric tests (15 minute dc) are to be conducted on an underground system with apparatus connected, be sure vacuum interrupter contacts are closed.

6. Normal electrical safety precautions should be observed.

Apparatus Type Designation	Interrupter Rated Maximum Voltage (kv ac rms)	75% of Rated Low-Frequency Withstand Voltage (kv ac rms) (1 min. dry)	Recommended D-C Withstand Voltage (kv dc)* (1 min. dry)	Recommended Open-Contact Gap (inches) (mm)
Column A	Column B	Column C	Column D	Column E
VAC-15.5-20	15.5	37.5	53	1/2 (12.7)

*To prevent possible interrupter damage, d-c test source should be limited to 100 milliamps maximum.

Mechanical

Check all fasteners for tightness. After the first 500 operations, all fasteners should be retorqued to standard values as follows:

1/4 - 20	8 ft-lb (11 N-m)
5/16 - 18	17 ft-lb (23 N-m)
3/8 - 16	30 ft-lb (41 N-m)
1/2 - 13	75 ft-lb (102 N-m)

N-m = Newton-meters

NOTE: These torque values do not apply to fasteners tapped in aluminum.

Operating Mechanism

NOTE: Also see S290-54-1 Type MO-1 Operating Mechanism Service Information.

1. Listen for excessive noise or bearing rumble in motor.
 2. Check linkage for signs of wear.
 3. Check for hydraulic leaks.
 4. Check hydraulic fluid level in sump.
 - A. Check level with closing spring discharged.
 - B. Dip stick connected to fill hole plug indicates fluid level.
 - C. An empty hydraulic system requires approximately 1-1/2 pints of fluid to fill the sump.
 - D. Add hydraulic fluid through fill-hole with one of the recommended hydraulic fluids to proper level.
- NOTE: Recommended fluids are: Chevron Oil Company Aviation Hydraulic Fluid A, Texaco Inc. Aircraft BB Hydraulic Oil, Shell Oil Company Aeroshell Fluid #4, Exxon Company Unisolv J-43.

Bushings

1. Bushings should be cleaned at regular intervals where abnormal conditions prevail such as salt deposits or any accumulation of foreign substances.
2. Bushing porcelain should be checked for cracks or chips.
3. If a bushing must be replaced refer to Bushings in the Parts Replacement section.

Make this replacement before proceeding to the next maintenance step.

NOTE: If any change in—or addition to—bushing current transformers is desired, make the change or addition at the same time the bushing is replaced.

Bushing Current Transformers

Check the bushing current transformer visually to make sure the leads are intact.

NOTE: If a change in—or addition to—bushing current transformers is desired, refer to Bushing Current Transformers in the Parts Replacement section and Service Information S290-80-2, Type OE Bushing Current Transformer Instructions. Make this change or addition before proceeding to the next maintenance step.

SAFETY PRECAUTION

Current transformer secondaries not connected to relays, instruments, or meters must be short-circuited and grounded at the terminal blocks in the low-voltage compartment.

Top-of-Bushing Terminal-to-Terminal Resistance

1. With the breaker closed conduct a top-of-bushing terminal-to-terminal resistance test on each of the three breaker poles (Figure 2).

NOTE: Resistance test results indicate the current carrying condition of the breaker not its ability to interrupt faults.

Electrical Resistance Level	Electrical Resistance* (microohms)	
	1200 Amp Breaker	2000 Amp Breaker
Normal	100 ± 15	35 to 40
Caution	125	42
Service Limit	135	45

*Measured externally—terminal-to-terminal with the breaker closed. Resistance values must be maintained below the caution level.

2. If resistance test values are at or above the caution level shown in the table, make the following checks and rectify as necessary.
 - A. Check the current carrying path of each pole for contamination. Wipe all current carrying parts with a clean, lint-free rag.
 - B. Check all connections in the current carrying path for tightness. All fasteners should be secure *but be sure to observe standard torque values mentioned under Mechanical of the Maintenance and Adjustment section.*
3. With the breaker closed, recheck the top-of-bushing, terminal-to-terminal resistance values.

NOTE: The resistance of vacuum interrupter contacts does not vary appreciably throughout interrupter life and therefore does not contribute to a change in terminal-to-terminal resistance.

Contact Wear

1. To check contact wear, the breaker contacts must be closed.
2. When the scribe mark on the movable contact rod (Figure 11) is even with the insulation guide, the interrupter must be replaced. See interrupter under Parts Replacement section.

- B. Time travel device can be set up on the floor of low-voltage compartment behind the mechanism.
 - C. Connect time travel device directly to the crank provided on the jack shaft assembly (Figure 4).
 - D. Record direct readings of contact speed/motion characteristics.
 - E. Disconnect time travel device from crank on jack shaft.
16. Check all painted surfaces making sure they are clean. Retouch painted surfaces where necessary for complete protection.
 17. Place the breaker and operator in the following service-ready condition.
 - A. Breaker in the open position.
 - B. Closing spring charged.
 - C. Heaters in the low-voltage compartment energized.
 18. Establish permanent service records.
 - A. Record the operation-counter registration.
 - B. Record pertinent facts regarding the condition of the breaker.
 - C. Record complete nameplate information.

MAINTENANCE AND ADJUSTMENT

The frequency of routine inspections depends on the degree of exposure to contamination and severity of the operating duty. It is suggested practice to inspect the breaker at 500 mechanical operation intervals or after a severe fault interruption near the maximum rating of the breaker. All adjustments are factory set and further adjustment should not be required unless the breaker has had severe wear or rough handling. Operating mechanism maintenance covered by S290-54-1, MO-1 Operation Mechanism Instructions, must be coordinated with the Type VAC breaker maintenance.

Keep complete records of all maintenance work performed.

SAFETY PRECAUTIONS

Before performing any maintenance on a Type VAC vacuum circuit breaker, the breaker must be removed from service.

Refer to and follow instructions in Service Information S290-54-1, Type MO-1 Operating Mechanism prior to making any maintenance checks.

Use the operating mechanism maintenance-positioning wrench during the performance of some of the maintenance steps. Observe all safety precautions in S290-54-1 as well as those throughout these instructions when performing maintenance.

Although the Type VAC breaker was designed with the safety of operating personnel foremost in mind, the inherent mechanical characteristics of the breaker along with the necessary activities of operating personnel make cautious work habits essential.

MATERIALS

- Clean, lint-free rags.
- Lubricants.

Wipe all parts to be lubricated with clean, lint-free rags. Lubricate non-current-carrying moving parts such as operating linkages, pins, roller bearings, and gear teeth with a light film of Humble Oil and Refining Lidok 000 grease.

Wipe off excess grease with clean, lint-free rags.

NOTE: Roller bearings require packing only after they have been removed for a complete overhaul.

- Cleaning solution.

The preferred cleaning solutions are heptane, Stoddard's solvent or cleaner's naphtha.

WARNING

Preferred cleaning solutions are flammable. Avoid sparks and flames. Use in an area where there is adequate ventilation.

WARNING

Deenergize the circuit breaker before performing any maintenance or inspection work. Unless stated otherwise in the procedure, all maintenance and inspection should be performed with the breaker open and the closing spring discharged.

Contact position indicator must read OPEN.

Closing spring position indicator must read DISCHARGED.

PROCEDURES

Cleanliness is the best assurance of trouble-free operation. If it is necessary to replace or adjust a breaker component, refer to Adjustments and Parts Replacement.

Wiring Checks

1. Terminal strip—check all connections and mounting screws to insure tightness. Check terminal strips for cracks.
2. Auxiliary switch—check all connections and mounting screws to insure tightness. Check for cracks and contact burns. Check the drive linkage.
3. Micro switches—check all connections for tightness, no cracks, and to insure plunger operates switch (a test light or ohmmeter can be used).

NOTE: Capacity of the ground connection should be sufficient to carry—without damage—the full ground short circuit of the system.

C. Install grounding connection.

4. Remove all packing materials from both compartments.
5. Check all fasteners for tightness. Secure but do not overtighten.
6. Remove operator blocking as follows:
 - A. Open rear door of low-voltage compartment.

NOTE: Be careful not to damage gasket.

- B. Use maintenance positioning wrench as illustrated (Figure 10).
- C. Apply upward force toward closing position to relieve pressure on blocking pin.
- D. Remove blocking pin.
- E. Very slowly relieve the force on maintenance closing wrench until breaker is fully open.
- F. Reseal low-voltage compartment.




Figure 10

To remove blocking rod from Type MO-1 operating mechanism use maintenance positioning wrench.

CONNECTIONS

1. Make line, auxiliary and control connection as overall installation progresses and as indicated on drawings.

SAFETY PRECAUTION

Main (load) connections should not impose more than a 100-pound (444.8 newtons) maximum cantilever pull on the bushings. Forces may be caused by expansion, contraction, wind loading, or foundation movement.

CAUTION

When making line connections, do not torque the bushing top-terminal assembly over 60 ft-lb (81.4 newton-meters); overtightening the bushing top terminal assembly will turn the core in the bushing, thus breaking the internal ground lead.

2. Prepare the operating mechanism for service in accordance with Service Information S290-54-1, Type MO-1 Operating Mechanism.

NOTE: If permanent heater connections cannot be made promptly, a temporary supply should be provided to prevent moisture condensation in the mechanism cabinet.

3. To operate the breaker during installation if permanent source is not available, temporary a-c and d-c power must be made available.
4. Make sure all internal and external fasteners are tight.
5. Make sure all entrance bushings are clean.
6. Check the bushing current transformers visually to make sure the leads are intact.

SAFETY PRECAUTION

Current transformer secondaries not connected to relays, instruments, or meters must be short-circuited and grounded at the terminal blocks in the low-voltage compartment.

7. Make sure that the operating mechanism is ready for normal operation and that all safety blocking has been removed. Refer to and follow Service Information S290-54-1, Type MO-1 Operating Mechanism Instructions.
8. Connect a temporary two-pushbutton station with open and close buttons close enough together to coordinate electrical control of the breaker.

NOTE: Refer to and follow connection diagrams that accompany the breaker.

9. After the mechanism blocking has been removed in accordance with previous instructions, the breaker is in the open position with the closing spring and opening springs discharged.
10. Energize the control circuit and charge the closing spring. When the closing spring is compressed, the breaker is ready for a closing operation.

NOTE: Closing spring can also be charged by hand pumping (Figure 7).

11. To close breaker momentarily energize closing circuit. Breaker should close instantly.
12. To open breaker momentarily energize opening circuit. Breaker should open instantly.
13. Using the temporary electrical controls repeat the closing and opening operations.
14. With the breaker open check the operation of the Y (anti-pump) relay.
 - A. Close the opening switch and hold it.
 - B. Close the closing switch and hold it. The breaker should close and open and remain open.
15. Perform time travel tests (optional).
 - A. Using the operating mechanism maintenance positioning wrench (Figure 10), close the breaker.




Figure 7
Manual charging of closing springs.




Figure 8
Typical hinged relay panel (optional).




Figure 9
Typical hinged ME electronic control panel (optional).

Contact position is indicated by an externally visible flag indicator. The manual trip can be furnished with a permissive control device as an option to prevent reclosure without operating an internal manual reset. Various convenient locations are provided for terminal blocks.

INSTALLATION

SAFETY PRECAUTIONS

It is extremely important that all safety precautions described in Service Information S290-54-1, Type MO-1 Operating Mechanism Instructions, be clearly understood and carefully followed.

Personnel performing work on a Type VAC vacuum breaker or a Type MO-1 operating mechanism must clearly understand and follow both the breaker instructions and the operating mechanism instructions.

When it is necessary to use the operating mechanism for operational checks, stay clear of all moving parts.

Although the Type VAC breaker was designed with the safety of operating personnel foremost in mind, the inherent mechanical characteristics of the breakers along with the necessary activities of operating personnel make cautious work habits essential.

If not already accomplished, adjust leg extensions to specified height as prescribed under Unloading or Moving section.

WARNING

Remember that all Type VAC breakers are shipped at minimum possible height and customer must adjust breaker height to insure compliance with safety codes for clearance.

FOUNDATION

1. To adjust leg extensions remove four bolts from each leg.
 - A. Slide leg downward to proper position and replace bolts.
 - B. Make sure shipping holddown clips at side of breaker have been removed and discarded.
2. Continue with installation by leveling and anchoring the breaker.
 - A. Prepare a flat slab or concrete piers to meet foundation requirements of drawings submitted for the breaker.
 - B. Level breaker and bolt solidly in position at points indicated on outline drawing.
 - (1) Shims of generous area should be located as required to insure even load distribution.
 - (2) Check for level in lateral and longitudinal directions with spirit level.
3. Ground breaker as follows:
 - A. Clean ground pad.
 - B. Two ground pads with standard NEMA drilling are furnished on breaker legs.




Figure 6
Sling arrangement.

STORAGE

If the Type VAC breaker is not to be placed in the service-ready condition immediately upon receipt, it is considered to be in storage. To prepare a breaker for storage:

1. Open the high-voltage compartment by removing cover plate bolts.
2. Open the low-voltage mechanism compartment.
3. Remove all packing material that might possibly collect moisture from both compartments.
 - A. Do not remove desiccants, if furnished, at this time. Desiccants should be maintained in effective condition until such time as the breaker is made ready for service.
 - B. Do not remove any blocking or bracing at this time.
 - C. Open all boxes, inspect, and reseal.
 - D. Store all boxes indoors in a dry place.

- E. Inspect the interiors of both compartments to insure they are clean and free from foreign materials.
4. Inspect bushings thoroughly. Make sure all bushings are clean, dry, and in good condition.
5. Energize compartment heaters with a temporary electrical source until permanent connections can be made.
6. Insure all openings are properly resealed to exclude moisture.
7. Close both compartments.

DESCRIPTION

The McGraw-Edison Type VAC vacuum circuit breaker is a three pole, integrally housed, electrically operated breaker suitable for outdoor operation. The operating mechanism is an electric-motor charged, compressed-spring stored energy Type MO-1. It is mechanically and electrically trip free. For detailed information on the Type MO-1 operating mechanism, refer to Service Information S290-54-1.

The Type VAC vacuum breaker should only be installed on circuits which operate within the voltages or currents given on the nameplate. Short-circuit conditions imposed on the breaker must not exceed the breaker rating.

HIGH-VOLTAGE COMPARTMENT

The upper section of the enclosure is the high-voltage compartment of the breaker. Contained therein are the lower ends of the bushings, current transformers, vacuum interrupters, transfer means, supporting stand off insulators, and operating rods to the interrupters. Access is by means of two bolted, hinged and gasketed panels. Except for an aluminum roof, the entire structure is heavy-gauge steel, treated and painted to inhibit corrosion.

The single- or multiple-ratio bushing current transformers are attached to the roof with all leads terminating at terminal blocks in the low-voltage compartment. The movable contact combination support-transfer scheme affords excellent repetitive guidance to the movable terminal for control of contact orientation and maximum bellows life.

LOW-VOLTAGE COMPARTMENT

The lower portion of the enclosure is the low-voltage compartment of the breaker which contains all control devices and the operator.

The Type MO-1 operator consists of a motor-driven, spring-stored-energy mechanism. Contact position indication and operations counter are visible with compartment door closed. The manual trip function is externally accessible. A means of manually charging the closing springs in case of charging power failure or for maintenance purposes is provided. Access to the opposite side of the low-voltage compartment is by means of a hinged, gasketed door with provisions for padlocking. (Some breakers are equipped with hinged relay panels or Type ME electronic controls which are mounted at the rear of the low-voltage compartment.




Figure 4
Low-voltage compartment.

INITIAL INSPECTION

Refer to Service Information S290-54-1, Type MO-1 Operating Mechanism Instructions, for initial inspection of the operating mechanism.

NOTE: Do not remove bracing or blocking from the operating mechanism at this time.

Immediately upon receipt of the breaker:

1. Check breaker exterior for evidence of damage in transit.
2. Open mechanism cabinet door and inspect low-voltage compartment for evidence of rough handling or damage in transit.
3. Close and latch the mechanism cabinet door to prevent entrance of dirt and moisture.
4. Open the front and rear panels (hinged and bolted) of the high-voltage compartment.
5. Inspect the interior of the high-voltage compartment for evidence of damage to the vacuum interrupter, bushings, and linkage due to rough handling in transit.
6. Reseal both front and rear openings promptly.
7. Remove all masking tape (later removal may be very difficult).
8. Secure bolts on both front and rear panels.

Should this initial inspection reveal evidence of rough handling or damage in transit or shortage, notify and file a claim with the carrier at once. Also notify the Service Department, McGraw-Edison Power Systems Division, Canonsburg, Pennsylvania 15317.

IDENTIFICATION RECORDS

Retain permanently complete identification records for each breaker including detailed outline drawings, control drawings, connection diagrams, and all pertinent instructions.

Accurate and complete identification including serial number and rating must accompany any reference to or inquiry about the breaker to McGraw-Edison Power Systems Division.

UNLOADING OR MOVING

The Type VAC breaker should be unloaded and moved by hoisting. Slings used for hoisting must have adequate lifting capacity. The weight of each breaker is shown on its nameplate. Attach slings at the top of each side of the breaker as illustrated (Figure 6).

WARNING

Do not permit sling to bear against porcelain bushings. Do not use holddown angles to lift breakers.



Figure 5
Do not use holddown angles to lift breakers.

With slings properly secured lift breaker straight up being careful not to damage the bushings with the rigging.

While breaker is off the ground adjust leg extensions per specific height requirements.

WARNING

For shipping convenience all Type VAC breakers are assembled and shipped with the minimum height possible. Customer must adjust breaker height to comply with electrical safety codes for clearance.

Remove and discard shipping holddown bolts and clips. Height adjustment is accomplished by removing four bolts from each leg, slide leg downward to proper position and replace the bolts.




Figure 2
Outline of type Type VAC, 15.5 kv vacuum circuit breaker.

SHIPPING

Except in special cases, each Type VAC breaker is shipped completely assembled with the MO-1 operating mechanism in place. Small accessory items are shipped in suitably marked packages.

Each breaker is shipped with the contacts blocked closed by a red rod inserted in the mechanism. The mechanism is unlatched so that opening-spring pressure is on the rod. For removal of this rod refer to the Installation section of these instructions and Type MO-1 Operating Mechanism Service Information S290-54-1.

Detailed outline drawings, control drawings, connection diagrams, all pertinent instructions, and packing lists are shipped protected in the mechanism cabinet. A shipping list in a weatherproof envelope is attached to each shipment.

NOTE: Breakers shipped overseas require special disassembled packaging.




Figure 3
High-voltage compartment.




Figure 1

A typical McGraw-Edison 15.5 kv Type VAC vacuum circuit breaker.

CONTENTS

GENERAL	1
Shipping	2
Initial Inspection	3
Identification Records	3
Unloading or Moving	3
Storage	4
DESCRIPTION	4
High-Voltage Compartment	4
Low-Voltage Compartment	4
INSTALLATION	5
Foundation	5
Connections	6

MAINTENANCE AND ADJUSTMENT	7
Materials	7
Procedures	7
Wiring Checks	7
Mechanical	8
Operating Mechanism	8
Bushings	8
Bushing Current Transformers	8
Top-of-Bushing Terminal-to-Terminal Resistance	8
Contact Wear	8
Vacuum Interrupter Test	9
Time Travel Test	10
PARTS REPLACEMENT	10
Bushings	10
Bushing Current Transformers	11
Vacuum Interrupters	11
SPARE PARTS	14

GENERAL

Service Information S290-10-1 pertains specifically to McGraw-Edison 15.5 kv Type VAC vacuum circuit breakers. Detailed outline, control drawings, and connection diagrams are issued for and accompany each breaker.

When installing, performing maintenance work, making adjustments, or replacing parts on a 15.5 kv Type VAC vacuum circuit breaker, the latest revision of the following instructions—copies of which accompany each breaker—must be followed.

Operating Mechanism: Service Information S290-54-1, Type MO-1 Operating Mechanism

Bushing Current Transformers: Service Information S290-80-2, Type OE Bushing Current Transformers

Separate instruction books are furnished for relays and auxiliary switches as required for each application.

Type VAC vacuum breakers conform to all applicable national standards for electrical characteristics, mechanical features, and accessories. Auxiliary provisions include an external trip device, a mechanical position indicator, trip counter, and facilities for proper mounting and electrical grounding.

Standard NEMA terminal designations are shown in Figure 2. Facing the mechanism side of the low-voltage compartment from front to rear, terminals are numbered 1 and 2 on the right, 3 and 4 in the center, and 5 and 6 on the left.

These instructions do not claim to cover all details or variations in the equipment, procedure, or process described, nor to provide directions for meeting every possible contingency during installation, operation, or maintenance. When additional information is desired to satisfy a problem not covered sufficiently for the user's purpose, please contact your McGraw-Edison Power Systems Division sales engineer.

C-ORDER# C-03956-4 ITEM# 01 REVISION# 00
 FOR: P.O.# LCCP55569A CONSOLIDATED ALUMINUM CORP
 VAC00 15.5 KV 1200A 20 KA

FOR IT. LOCATION REFER TO MECHANISM CONNECTION DIAGRAM SHC03231A
 ** - INDICATES CHANGE FROM LAST REVISION #

D E S C R I P T I O N

ITEM#	QTY	U/M	MEPS NO.	
24	1	EA	333041055	50-103131LSSJ, AMMETER, 0-600 AMP AC, 60 HZ, SEMI-FLUSH MOUNTING, GENERAL ELECTRIC TYPE AB-40.
25	1	EA	323021153	16S81CA19X2, AMMETER SWITCH, FIXED KNURLED HANDLE, GENERAL ELECTRIC TYPE SB-1.
26	1	EA		50-103021PZXE, VOLTMETER, 0-150 VOLT AC RATING, 0-18 KV SCALE, 60 HZ, SEMI-FLUSH MOUNTING, GENERAL ELECTRIC TYPE AB-40. (FOR USE WITH 14,400-120 VOLT P.T.'S CONN. IN DELTA ON A 13.8 KV SYSTEM.)
27	1	EA		16S81CF11X2, VOLTMETER SWITCH, FIXED KNURLED HANDLE, GENERAL ELECTRIC TYPE SB-1.

CKD.	<i>[Signature]</i>	DATE	3/5/82
APP'D.	<i>[Signature]</i>	DATE	3-5-82

C-ORDER# C-03950-4 ITEM# V1 REVISION# 00
FOR: P.O.# LCCP55569A CONSOLIDATED ALUMINUM CURP
VAC00 15.5 KV 1200A 20 KA

FOR IT. LOCATION REFER TO MECHANISM CONNECTION DIAGRAM SHC03231A
** - INDICATES CHANGE FROM LAST REVISION #

ITEM#	QTY	U/M	MEPS NO.	D E S C R I P T I O N
13	42	EA	351045U17	YAU 10-10 UR #33457, TERMINAL, KING TONGUE, WIRE RANGE 12-10, BURNNDY OR AMP.
14	1	EA	SVC00132A001	MECHANISM CONTROL PANEL.
15	1	EA	SVC00133A001	CT TERMINAL BLOCK PANEL.
16	1	EA	SVB00257A00B	HEATER ASSEMBLY, 250 WATT, 240 VOLT.
17	1	EA	SVA00960A001	RELAY PANEL
18	1	EA	SVA00889A00A	METER PANEL FRAME, STANDARD WIDTH, FOR VAC BREAKER.
19	4	EA		264C900A06, OVERCURRENT RELAY, 60 HZ, 1-12 AMP MAIN, INVERSE TIME, WESTINGHOUSE TYPE CO-8.
20	1	EA		121JCS1B4A, CURRENT BALANCE RELAY, THREE PHASE, 60 HZ, 5 AMP, GENERAL ELECTRIC TYPE 1JC
21	1	EA	323021101	16SB1B1X2, CIRCUIT BREAKER CONTROL SWITCH, PISTOL GRIP HANDLE, GENERAL ELECTRIC TYPE SB-1.
22	1	EA	SHB00984A00E	INDICATING LIGHT ASSEMBLY, 240 VOLT AC, WITH RED COLOR CAP, GENERAL ELECTRIC TYPE ET-16.
23	1	EA	SHB00984A00K	INDICATING LIGHT ASSEMBLY, 240 VOLT AC, WITH GREEN COLOR CAP, GENERAL ELECTRIC TYPE ET-16.

CKD.	10	DATE	3/3/82
APPD.	10	DATE	5-8-82

C-ORDER# C-03956-4 ITEM# 01 REVISION# 00
FOR: P.O.# LCCP55569A CONSOLIDATED ALUMINUM CORP
VACUUM 15.5 KV 1200A 20 KA

FOR IT. LOCATION REFER TO MECHANISM CONNECTION DIAGRAM SHC03231A
** - INDICATES CHANGE FROM LAST REVISION #

ITEM#	QTY	U/M	MEPS NO.	DESCRIPTION
1	2	EA	SHB00701A00E	AUXILIARY RELAY, 230 VAC, SURFACE MOUNTED, FRONT CONNECTED, GENERAL ELECTRIC TYPE CR205.
2	1	EA	334061213	MODEL 295-240, CAPACITOR TRIP DEVICE, 208/240 VAC SOURCE, TIME MARK CORPORATION.
3	2	EA	323021313	TC-1130, KNIFE SWITCH, 30 AMP, 250 VOLT, 2 POLE, OPEN TYPE FUSED, GENERAL ELECTRIC.
4	1	EA	323021312	TC-3041, KNIFE SWITCH, 30 AMP, 250 VOLT, 2 POLE, OPEN TYPE UNFUSED, GENERAL ELECTRIC.
5	1	EA	351071152	FUSE BLOCK, 30 AMP, 250 VOLT, 2 POLE.
6	4	EA	351071463	NON-15, FUSE, CARTRIDGE TYPE, 15 AMP, 250 VOLT, BUSSMANN.
7	2	EA	351071467	NON-30, FUSE, CARTRIDGE TYPE, 30 AMP, 250 VOLT, BUSSMANN.
8	1	EA	334041371	RESISTOR, 25 OHM, 175 WATT.
9	3	EA	351063919	1612, TERMINAL BLOCK, 12 POLE, 30 AMP, 600 VOLT, MARATHON.
10	6	EA	351063905	1606-SC, TERMINAL BLOCK, 6 POLE, 30 AMP, 600 VOLT, SHORT CIRCUITING, MARATHON.
11	800	FT	236041533	CU. WIRE, SYN901, #14-41 STR, BLACK. (MECHANISM AND RELAY CABINET WIRING)
12	200	EA	351045011	34123 OR BB-339-10, TERMINAL, RING TONGUE, WIRE RANGE

CKD.	U	DATE	3/1/82
APPD.	<i>[Signature]</i>	DATE	3-5-82

McGRAW-EDISON

POWER SYSTEMS DIVISION

BTCT RATIO CORRECTION FACTOR CURVES

ASA STANDARD B-2(2 OHMS, 50 PERCENT PF LAG) SEC BURDEN

MARKED RATIO	SEC. TURNS	SEC. TAPS
100/5	20	X ₂ -X ₃
200/5	40	X ₁ -X ₂
300/5	60	X ₁ -X ₃
400/5	80	X ₄ -X ₅
500/5	100	X ₃ -X ₄
600/5	120	X ₂ -X ₄
800/5	160	X ₁ -X ₄
900/5	180	X ₃ -X ₅
1000/5	200	X ₂ -X ₅
1200/5	240	X ₁ -X ₅

TYPE OE- 1200

DWG. NO. A-385575

OCB TYPE-


FREQUENCY 60 CYCLES

MAXIMUM RATIO 1200/5

TOTAL SEC. TURNS 240

SEC. RES. .0019 OHMS/TURN + .052 OHMS @ 75°C

ASA ACCURACY 10C200



PERCENT RATED CURRENT Dwg. No. RCF-385575-2C

DOTTED LINE - SECONDARY COORDINATE

SOLID LINE - PRIMARY COORDINATE

McGraw-Edison

POWER SYSTEMS DIVISION

BTCT EXCITING CURRENT CURVES

TYPE OE- 1200

DWG. NO. A-385575

OCB TYPE -

FREQUENCY 60 CYCLES

MAXIMUM RATIO 1200/5


TOTAL SEC. TURNS 240

SEC. RES. .0019 OHMS/TURN + .052 OHMS @ 75°C

ASA ACCURACY 10C200

MARKED RATIO	SEC. TURNS	SEC. TAPS
100/5	20	X ₂ -X ₃
200/5	40	X ₁ -X ₂
300/5	60	X ₁ -X ₃
400/5	80	X ₄ -X ₅
500/5	100	X ₃ -X ₄
600/5	120	X ₂ -X ₄
800/5	160	X ₁ -X ₄
900/5	180	X ₃ -X ₅
1000/5	200	X ₂ -X ₅
1200/5	240	X ₁ -X ₅

1200/5	1000/5	900/5	800/5	600/5	500/5	400/5	300/5	200/5	100/5
--------	--------	-------	-------	-------	-------	-------	-------	-------	-------



Dwg. No. 1X-385575-1




DIAGRAM ABBREVIATIONS *

A	AMPERE	ELEC	ELECTRIC	LSS	LEFT SIDE SHEET	s	SECONDS
AC	ALTERNATING CURRENT	ELEM	ELEMENTARY	LT	LIGHT	SEC	SECONDARY
ACB	AIR CIRCUIT BREAKER	EMER	EMERGENCY	LTG	LIGHTING	SECT	SECTION
Am	AMMETER	ENCL	ENCLOSURE	LV	LOW VOLTAGE	SEQ	SEQUENCE
ANN	ANNUNCIATOR	EQ	EQUALIZER	mAm	MILLIAMMETER	SER	SERIES
APM	ARMATURE	EQUIP	EQUIPMENT	MAN	MANUAL	SH	SHUNT
	AMMETER SWITCH	EXC	EXCITER; EXCITATION	MAN OP	MANUALLY OPERATED	SI	SEAL-IN DEVICE
	AUTOMATIC	EXIST	EXISTING	MC	METAL-CLAD	SOL	SOLENOID
AUTO RECL	AUTOMATIC RECLOSING	FB	FUSE BLOCK	MCM	THOUSAND CIRCULAR MILS	SP	SPARE
AUTO T	AUTO TRANSFORMER	FC	FRONT CONNECTED			SPDT	SINGLE POLE DOUBLE THROW
AUX	AUXILIARY	FDR	FEEDER	MECH	MECHANICAL MECHANISM	SPST	SINGLE POLE SINGLE THROW
BASw	BELL ALARM SWITCH	FIG	FIGURE	μF	MICROFARAD	STA	STATION; STATIONARY
BAT	BATTERY	FLD	FIELD	MFR	MANUFACTURER	STAB	STABILIZER
BAT CHG	BATTERY CHARGER	FLEX	FLEXIBLE	MG	MOTOR GENERATOR	STD	STANDARD
BB	BENCH BOARD	f	FREQUENCY	MISC	MISCELLANEOUS	STG	STARTING
BC	RACK CONNECTED	FRWK	FRAMEWORK	M	MOTOR	STR	STRUCTURE
BCT	BUSHING CURRENT TRANSFORMER	FU	FUSE	MTD	MOUNTED	SUB STA	SUBSTATION
BD	BOARD	FUT	FUTURE	mV	MILLIVOLT	SUPV	SUPERVISORY
BE	BREAKER END	FV	FRONT VIEW	NC	NORMALLY CLOSED	Sw	SWITCH
BKR	BREAKER	FWD	FORWARD	NEG	NEGATIVE	SWBD	SWITCHBOARD
BPD	BUSHING POTENTIAL DEVICE	G	GENERATOR	NEUT	NEUTRAL	SWR BKT	SWINGING BRACKET
BRKT	BRACKET	GD	GROUND DETECTOR	NO	NORMALLY OPEN; NUMBER	SWGR	SWITCHGEAR
BV	BACK VIEW	GOV	GOVERNOR	NOR	NORMAL	SYM	SYMBOL
C	CURRENT	GRD	GROUND	NP	NAMEPLATE	SYN	SYNCHRONISM; SYNCHRONIZING; SYNCHRONOUS; SYNCHROSCOPE
CAB	CABINET	HC	HOLDING COIL	OC	OVERCURRENT	SYN CONV	SYNCHRONOUS CONVERTER
CAL	CALIBRATING	hp	HORSE POWER	OCB	OIL CIRCUIT BREAKER	SS	SYNCHRONIZING SWITCH
CAP	CAPACITOR; CAPACITY	HR	HAND RESET	OPER	OPERATE		
CAT	CATALOG	HTR	HEATER	OVL	OVERLOAD	TB	TERMINAL BLOCK
CC	CLOSING COIL	HV	HIGH VOLTAGE	PH	PHASE	TC	TRIP COIL
CKT	CIRCUIT	IMPR	IMPEDOR	PB	PUSH BUTTON	TD	TESTING DEVICE
CNTOR	CONTACTOR	INCMG	INCOMING	PB STA	PUSH BUTTON STATION	TDC	TIME DELAY CLOSING
CO	CUT OUT	INST	INSTANTANEOUS; INSTRUMENT	PCB	POWER CIRCUIT BREAKER	TDG	TIME DELAY OPENING
COMP	COMPENSATOR	INT CONN	INTERNAL CONNECTION	PF	POWER FACTOR	TEL	TELEPHONE
COMPT	COMPARTMENT	IT	INSULATING TRANSFORMER	PFD	PREFERRED	TELE	TELEMETER
CONN	CONNECT CONNECTION			PfM	POWER FACTOR METER	TEMP	TEMPERATURE
CONT	CONTINUED; CONTROL	kV	KILOVOLT	PH	POTHEAD	TERM	TERMINAL
CONV	CONVERTER	kVA	KILOVOLT AMPERE	PNEU	PNEUMATIC	Tm	TEMPERATURE METER
CPT	CONTROL POWER TRANSFORMER	kVAh	KILOVOLT AMPERE HOUR	PNL	PANEL	TPST	TRIPLE POLE SINGLE THROW TRANSFORMER
CR	CONTROL RELAY	kVAhm	KILOVOLT AMPERE HOUR METER	POS	POSITION, POSITIVE		
CS	CONTROL SWITCH	kVAm	KILOVOLT AMPERE METER	POT	POTENTIAL	UV	UNDERVOLTAGE
CT	CURRENT TRANSFORMER	kvar	KILOVOLT-AMPERE REACTIVE	PRI	PRIMARY	UVD	UNDERVOLTAGE DEVICE
C	CYCLE	kvarh	KILOVAR HOUR	PT	POTENTIAL TRANSFORMER	V	VOLT
DC	DIRECT CURRENT	kW	KILOWATT	PU	PICK UP	VA	VOLT-AMPERE
DD	DISCONNECTING DEVICE	kWh	KILOWATT HOUR	PWR	POWER	vac	VACUUM
DEV	DEVICE	kWhm	KILOWATT HOUR METER	RCD	REVERSE CURRENT DEVICE	V ADJ R	VOLTAGE ADJUSTING RHEOSTAT
DIAG	DIAGRAM	L	LAMP; LOWERING	RE	RECEPTACLE	var	VOLT-AMPERE REACTIVE
DIFF	DIFFERENTIAL	LA	LIGHTNING ARRESTER	REAC	REACTOR	varh	VAR HOUR
DIR	DIRECTION, DIRECTIONAL	LC	LATCH CHECK	RECL	RECORDING	varm	VARMETER
DISC	DISCONNECT	LH	LEFT HAND	RECT	RECTIFIER	Vm	VOLTMETER
DISCH	DISCHARGE	LIR	LOAD INDICATING RESISTOR	REG	REGULATOR	V REG	VOLT REGULATOR
Dm	DEMAND METER	LLM	LOAD LIMITING RESISTOR	RES	RESISTANCE; RESISTOR	VS	VOLTMETER SWITCH
D	DRAWOUT	LRC	LOAD RATIO CONTROL	REV	REVERSE; REVISE		
DPST	DOUBLE POLE DOUBLE THROW	LSW	LIMIT SWITCH	RH	RIGHT HAND	W	WATT; WIRE
DSw	DISCONNECT SWITCH	LSR	LOAD SHIFTING RESISTOR	RHEO	RHEOSTAT	WhDm	WATTHOUR DEMAND METER
DSCT	DOUBLE SECONDARY CURRENT TRANSFORMER			RSS	RIGHT SIDE SHEET	Whm	WATTHOUR METER
DWG	DRAWING			RTD	RESISTANCE TEMPERATURE DETECTOR	Wm	WATTMETER
DX	DUPLEX			RV	REAR VIEW	Wt	WEIGHT

* Most Commonly Used Abbreviations.

1. Master Element	25. Synchronizing or Synchronism-Check Device	50. Instantaneous Overcurrent or Rate-of-Rise Relay	74. Alarm Relay
2. Time-Delay Starting or Closing Relay	26. Apparatus Thermal Device	51. A-C Time Overcurrent Relay	75. Position Changing Mechanism
3. Checking or Interlocking Relay	27. Undervoltage Relay	52. A-C Circuit Breaker	76. D-C Overcurrent Relay
4. Master Contactor	28. Flame Detector	53. Exciter or D-C Generator Relay	77. Pulse Transmitter
5. Stopping Device	29. Isolating Contactor	54. Reserved for future application	78. Phase Angle Measuring or Out-of-Step Protective Relay
6. Starting Circuit Breaker	30. Annunciator Relay	55. Power Factor Relay	79. A-C Reclosing Relay
7. Anode Circuit Breaker	31. Separate Excitation Device	56. Field Application Relay	80. Liquid or Gas Flow Relay
8. Control Power Disconnecting Device	32. Directional Power Relay	57. Short-Circuiting or Grounding Device	81. Frequency Relay
9. Reversing Device	33. Position Switch	58. Rectification Failure Relay	82. D-C Reclosing Relay
10. Unit Sequence Switch	34. Master Sequence Device	59. Overvoltage Relay	83. Automatic Selective Control or Transfer Relay
11. Reserved for future application	35. Brush-Operating or Slip-Ring Short-Circuiting Device	60. Voltage or Current Balance Relay	84. Operating Mechanism
12. Over-Speed Device	36. Polarity Device	61. Reserved for future application	85. Carrier or Pilot Wire Receiver Relay
13. Synchronous-Speed Device	37. Undercurrent or Underpower Relay	62. Time-Delay Stopping or Opening Relay	86. Locking-Out Relay
14. Under-Speed Device	38. Bearing Protective Device	63. Liquid or Gas Pressure or Vacuum Relay	87. Differential Protective Relay
15. Speed or Frequency Matching Device	39. Mechanical Condition Monitor	64. Ground Protective Relay	88. Auxiliary Motor or Motor Generator
16. Reserved for future application	40. Field Relay	65. Governor	89. Line Switch
17. Shunting or Discharge Switch	41. Field Circuit Breaker	66. Notching or Jogging Device	90. Regulating Device
18. Accelerating or Decelerating Device	42. Running Circuit Breaker	67. A-C Directional Overcurrent Relay	91. Voltage Directional Relay
19. Starting-to-Running Transition Contactor	43. Manual Transfer or Selector Device	68. Blocking Relay	92. Voltage and Power Directional Relay
20. Electrically Operated Valve	44. Unit Sequence Starting Relay	69. Permissive Control Device	93. Field Changing Contactor
21. Distance Relay	45. Atmospheric Condition Monitor	70. Electrically Operated Rheostat	94. Tripping or Trip-Free Relay
22. Equalizer Circuit Breaker	46. Reverse-Phase or Phase-Balance Current Relay	71. Liquid or Gas-Level Relay	95.
23. Temperature Control Device	47. Phase-Sequence Voltage Relay	72. D-C Circuit Breaker	96.
24. Reserved for future application	48. Incomplete Sequence Relay	73. Load-Resistor Contactor	97. Used only on specific applications on individual installations where none of the assigned numbered functions from 1 to 94 are suitable.
	49. Machine or Transformer Thermal Relay		

NOTES:

Suffix letters X, Y or Z are added to the appropriate device function numbers to denote separate auxiliary relays.

Example: 27X, 52Y, 79Z.

If two or more devices with the same function number and suffix letter (if used) are present in the same equipment, they may be distinguished by numbered suffixes. Example: 27-1, 27-2, 27X-1, 27X-2.

MISCELLANEOUS DEVICE DESIGNATIONS

52/X	CLOSING RELAY	52/UV	UNDERVOLTAGE TRIP
52/Y	ANTI-PUMP RELAY	24	BUS TIE BREAKER
52/CC	BREAKER CLOSING COIL	W/VS	WATT-VAR SWITCH
52/TC	BREAKER TRIP COIL	PTD	POTENTIAL TEST DEVICE
52/M	BREAKER PUMP MOTOR	CTD	CURRENT TEST DEVICE
52/SS	MOTOR CUTOFF HIGH PRESSURE SWITCH	VRR	VOLTAGE REGULATING RELAY
52/S	CONTROL CUTOFF LOW PRESSURE SWITCH	LTC	LOAD TAP CHANGER
	CLOSED WHEN PRESSURE IS SUFFICIENT FOR CLOSING	PST	PHASE SHIFTING TRANSFORMER
52/a	NORMALLY OPEN AUXILIARY SWITCH CONTACT	ETM	ELAPSED TIME METER
52/b	NORMALLY CLOSED AUXILIARY SWITCH CONTACT	201X	SUPERVISORY CLOSING DEVICE
52/aa	ADVANCE MAKE "a" CONTACT—CLOSES DURING FIRST 15° OF CLOSING MOTION	294X	SUPERVISORY TRIPPING DEVICE
52/ba	ADVANCE BREAK "b" CONTACT—OPENS DURING FIRST 15° OF CLOSING MOTION	43LS	LOCAL—SUPERVISORY TRANSFER SWITCH
52/Sa	STATIONARY SWITCH—MECHANISM OPERATED	43MA	MANUAL—AUTOMATIC TRANSFER SWITCH
52/Sb	IN TEST, OPERATE OR BOTH POSITIONS AS INDICATED	87L	PILOT WIRE RELAY
52/Ha	HOUSING SWITCH—TRUCK OPERATED, SHOWN	85/74-R	PILOT WIRE RECEIVING AND ALARM RELAY
52/Hb	WITH BREAKER IN TEST OR WITHDRAWN POSITION	85/74-S	PILOT WIRE SENDING AND ALARM RELAY
		50/CO	INSTANTANEOUS RELAY CUTOFF DEVICE
		79/CO	RECLOSER RELAY CUTOFF DEVICE

McGraw-Edison Power Systems Group
McGraw-Edison Company
Canonsburg, PA 15317 USA

CONTENTS

GENERAL	1
SHIPPING	2
INITIAL INSPECTION	3
IDENTIFICATION RECORDS	3
UNLOADING AND/OR MOVING FROM TRANSPORTING VEHICLE TO INSTALLATION LOCATION	3
PREPARING MECHANISM FOR STORAGE	3
PRINCIPLES OF OPERATION	3
Initial Charging of the Closing Spring	4
Closing Operation	4
Opening Operation	5
INSTALLATION	5
MAINTENANCE AND INSPECTION	6
Materials	6
Lubricants	6
Hydraulic Fluid	6
Auxiliary Switch	7
Close Coil	7
Close Coil Switch, Motor Cutoff Switch	7
Trip Coil	8
Trip Latch	8
Opening Buffer	8
Motor	8
Handpump	8
Dump Valve	8
Auxiliary Devices	8
Interior and Exterior Cabinet Surfaces	8
ADJUSTMENTS	9
Close Coil	9
Pressure-Release Valve, Close Coil Switch and Motor Cutoff Switch	9
Trip Latch	9
Trip Coil Armature Air Gap	10
Opening Buffer	10
Trip Latch Switch	11
Dump Valve	11
PARTS REPLACEMENT	11
Close Coil	11
Trip Coil	11
Auxiliary Switch	11
Motor	11
TROUBLESHOOTING	12




Figure 1
MO-1 operating mechanism mounted in low-voltage compartment of Type VAC vacuum circuit breaker.

GENERAL

Service Information S290-54-1 pertains specifically to the MO-1 operating mechanism, a hydraulically charged, spring-driven device that operates a McGraw-Edison vacuum circuit breaker electrically or manually at high speeds. The MO-1 operating mechanism is mounted in the low-voltage compartment of the vacuum circuit breaker (Figure 1).

Detailed connection diagrams are issued for and accompany each MO-1 operating mechanism.

When preparing an MO-1 operating mechanism for initial service, making in-service inspections, performing maintenance work, making adjustments, or replacing parts, the latest revision of the following instructions—copies of which accompany the breaker—must also be followed:

- Vacuum Circuit Breaker: applicable service information covering the vacuum circuit breaker in which the MO-1 operating mechanism is mounted.
- Bushing Current Transformers: Service Information S290-80-2, Type OE Bushing Current Transformers.

The MO-1 operating mechanism conforms to all applicable standards for electrical characteristics, mechanical features, and accessories.

These instructions do not claim to cover all details or variations in the equipment, procedure, or process described, nor to provide directions for meeting every possible contingency during installation, operation, or maintenance. When additional information is desired to satisfy a problem not covered sufficiently for the user's purpose, please contact your McGraw-Edison Power Systems Group sales engineer.




Figure 2
Auxiliary equipment and operator components.

- | | | | |
|--------------------------------|--|--|--|
| 1. Manual trip handle. | 7. Control wiring terminal blocks. | 11. Hinged relay panel with relays (optional). | 17. Crank for connecting time travel device. |
| 2. Contact position indicator. | 8. Control conduit entrance plate. | 12. Pump motor. | 18. Nut for adjusting operating rod length. |
| 3. Operations counter. | 9. Heaters (on cabinet wall, not shown). | 13. Socket for manual charge handle. | 19. Jackshaft. |
| 4. Auxiliary switch. | 10. Current transformer terminal blocks. | 14. Closing spring. | 20. Contact pressure springs. |
| 5. Auxiliary operating relays. | | 15. Closing spring indicator. | 21. Sump. |
| 6. Control supply switches. | | 16. Operating linkage. | |

SHIPPING

The MO-1 operating mechanism is shipped fully assembled and mounted in the low-voltage compartment of the vacuum circuit breaker.

Each breaker is shipped with the contacts blocked closed by a red rod inserted in the mechanism. The MO-1 mechanism is unlatched so that opening-spring pressure is

on the rod. For removal of this rod, refer to the Installation section of these instructions.

Detailed outline drawings, control drawings, connection diagrams, all pertinent instructions, and packing lists are shipped protected in each MO-1 operating mechanism cabinet.

NOTE: Breakers shipped overseas require special packaging.

INITIAL INSPECTION

Refer to the applicable vacuum circuit breaker instructions for initial inspection of the breaker.

NOTE: *Do not remove bracing or blocking from the operating mechanism at this time.*

Immediately upon receipt of the breaker:

1. Inspect the exterior and interior of the operating mechanism compartment for evidence of rough handling or damage in transit and shortage.
2. Remove all masking tape (later removal may be very difficult).
3. After checking the operating mechanism compartment interior, close the doors promptly to prevent entrance of dirt and moisture. Should this initial inspection reveal evidence of rough handling or damage in transit or shortage, notify and file a claim with the carrier at once. Also notify the Service Department, McGraw-Edison Power Systems Division, Canonsburg, Pennsylvania 15317.

IDENTIFICATION RECORDS

Retain, permanently, complete identification for each operating mechanism including connection wiring diagrams and all pertinent instructions.

Accurate and complete identification records—including the vacuum circuit breaker serial number and rating—must accompany any reference to, or inquiry about, the operating mechanism to McGraw-Edison Power Systems Division.

UNLOADING AND/OR MOVING FROM TRANSPORTING VEHICLE TO INSTALLATION LOCATION

When unloading or moving a breaker on which an MO-1 operating mechanism is mounted, the operating mechanism must be braced and blocked in the original shipping position. Refer to and follow the vacuum circuit breaker instructions for unloading or moving the breaker from the transporting vehicle to the installation location.

PREPARING MECHANISM FOR STORAGE

If a vacuum circuit breaker in which an MO-1 operating mechanism is mounted is not to be placed in the service-ready condition immediately upon receipt, it is considered to be in storage.

To prepare an MO-1 operating mechanism for storage:

1. Open the low-voltage compartment doors.
2. Check to be sure all bracing and blocking are secure, but do not remove any bracing or blocking at this time.
3. To prevent moisture from entering and damaging the operating mechanism, energize the cabinet heaters with a temporary electrical supply until permanent connections are made. *Refer to—and follow—the connection diagrams for heater circuit connections and voltage.*
4. Close the cabinet doors promptly.

PRINCIPLES OF OPERATION

Schematic representations, Figures 3, 4 and 5, illustrate the operating principles of the MO-1 operating mechanism.

In Figure 3 the breaker is open, the closing spring charging,




Figure 3

Breaker open, closing spring charging, hydraulic system operating.




Figure 4
Breaker open, closing spring charged, no hydraulic pressure.

and the hydraulic system operating. The trip link is in the collapsed position and the hold-on-latch is held down by the trip link. The closing spring must have an initial charge for the breaker to be operated.

INITIAL CHARGING OF THE CLOSING SPRING

1. As soon as control voltage is supplied, the motor-driven hydraulic pump forces hydraulic fluid into the charging cylinder.
2. The charging cylinder compresses the closing spring towards the charged position; drive block follows.
3. Charging cycle continues until the close latch engages the closing roller. At this time through the mechanical linkage a motor cutoff switch interrupts the supply voltage to the motor, completing the charging sequence (Figure 4).
4. Meanwhile, the movement of the drive block has set the trip link, trip roller on trip latch and closes a trip latch switch in series with the close coil.
5. Simultaneous with the completion of the charging sequence, the pressure-release valve opens to the sump relieving hydraulic pressure to the charging cylinder and permitting the close roller to load the close latch.
6. As the pressure-release valve opens, the poppet-type dump valve opens to the sump and brings the charging fluid to sump pressure.
7. As the close lever moves to the set position, the close

coil switch, in series with the close coil is made.

The breaker is now ready for a closing operation, Figure 4.

CLOSING OPERATION

1. After applying proper control voltage to the close coil, the closing roller is moved from under the close latch and the close latch is driven free by the force of closing spring.
 2. Charging cylinder moves forward forcing drive block along with it.
 3. Interconnecting links will rotate the drive crank and jackshaft and will close the breaker contacts.
 4. Hydraulic fluid is returned to the sump through the dump valve.
 5. Rotation of the drive crank and jackshaft compresses the opening springs.
 6. Mechanical linkage closes charging motor cutoff switch, energizing motor and closes pressure-release valve so that there is pressure in charging cylinder.
 7. Poppet-type dump valve closes.
 8. Charging cylinder moves closing spring to the charged position, Figure 5.
 9. Drive block is held in set position and trip link is loaded.
- The breaker is now ready for an opening operation. Figure 5.*




Figure 5
Breaker closed, closing spring charged, no hydraulic pressure.

OPENING OPERATION

1. When proper voltage is applied to the trip coil, the trip latch moves mechanically, allowing trip link to collapse by the component of force from the opening spring.
2. Interconnecting links rotate the drive crank and jack-shaft moving the breaker contacts into the open position.
3. As trip link collapses, hold-on latch disengages and drive block moves back toward charging cylinder and trip link resets, Figure 5.

When the trip latch resets, the trip roller and the trip latch switch is made up, the breaker is ready to be reclosed.

INSTALLATION

SAFETY PRECAUTIONS

It is extremely important that all safety precautions described in these instructions and the breaker instructions be clearly understood and carefully followed.

Although the MO-1 operating mechanism and the breaker on which it is mounted have been designed with the safety of operating personnel foremost in mind, the inherent mechanical characteristics of the breaker—along with the necessary activities of operating personnel—make cautious work habits essential.

The MO-1 operating mechanism is mounted and tested in the breaker before shipment. Since it is shipped mounted and mechanically complete, there is no actual installation work required. However, certain checks must be thoroughly performed.

It is necessary to fully understand the principles of operation of the MO-1 operator before any attempt is made to energize the control circuits. Before the mechanism is actuated, operation of the breaker should be understood and specific checks made.

Before preparing the MO-1 operating mechanism for service, prepare the foundation, level and bolt the breaker in place, and install grounding connections in accordance with the breaker instructions.

The MO-1 operating mechanism is adjusted at the factory. Ordinarily factory-set adjustments need not be altered.

To prepare an MO-1 operating mechanism for service:

1. Make electrical connections in accordance with the connection diagram furnished with the equipment.

NOTE: If a permanent supply is not available, make temporary electrical connections until permanent connections can be made.

CAUTION

Mechanism operating circuits should not be closed until called for in both the breaker and these mechanism instructions.

2. Check hydraulic fluid level in the sump.

NOTE: Closing spring must be discharged when checking fluid level.

A. Dip stick connected to fill hole plug indicates fluid level.

B. If addition of fluid is required, refer to the Maintenance section. *Correct this condition before proceeding to the next installation step.*

3. Remove any bracing or blocking placed in the relays for shipping purposes.

4. If not already accomplished, remove operator blocking as follows:

A. Open rear door of low-voltage compartment.

NOTE: Be careful not to damage gasket.

B. Use maintenance-positioning wrench as illustrated, Figure 6.

C. Apply upward force toward closed position to relieve pressure on blocking pin.

D. Remove blocking pin.

E. Using the maintenance-positioning wrench, very slowly relieve the opening spring force on the jackshaft until the breaker reaches the fully open position.

F. Reseal low-voltage compartment.

5. Energize the motor and control circuits with a permanent supply (or a temporary supply until a permanent power source is available).

6. *Refer to—and follow—the vacuum breaker instructions for final installation instructions.*

MAINTENANCE AND INSPECTION

Schedule and coordinate maintenance work on the MO-1 operating mechanism with maintenance work on the vacuum circuit breaker. Refer to—and follow—the instructions covering the breaker on which the MO-1 operating mechanism is mounted. Keep complete records of all maintenance work performed.

SAFETY PRECAUTIONS

The vacuum circuit breaker on which the MO-1 operating mechanism is mounted must be removed from service before performing any maintenance work on the operating mechanism or the breaker.

Use the operating mechanism maintenance-positioning wrench during the performance of some of the maintenance steps. Observe all Safety Precautions in the vacuum circuit breaker instructions as well as those throughout these instructions when performing maintenance.

Although the Type MO-1 operator was designed with the safety of operating personnel foremost in mind, the mechanical characteristics of the operating mechanism and breaker, along with the necessary activities of operating personnel, make cautious work habits essential.




Figure 6
Maintenance-positioning wrench permits manual rotation of jackshaft for blocking pin removal or for maintenance checks.

WARNING

Deenergize the circuit breaker before performing any maintenance or inspection work. Unless stated otherwise in the procedure, all maintenance and inspection should be performed with the breaker open and the closing spring discharged.

Contact position indicator must read OPEN. Closing spring position indicator must read DISCHARGED.

MATERIALS

- Clean-lint-free rags.
- Cleaning solutions.

The preferred cleaning solutions are heptane, Stoddard's solvent, or cleaner's naphtha.

WARNING

Preferred cleaning solutions are flammable. Avoid sparks and flames. Use in an area where there is adequate ventilation.

LUBRICANTS

Wipe all parts to be lubricated with clean, lint-free rags. Lubricate parts such as operating linkages, pins and roller bearings with a light film of Humble Oil and Refining Lidok 000 grease. Wipe off excess grease with clean lint-free rags.

NOTE: Roller bearings require packing only after they have been removed for a complete overhaul.

HYDRAULIC FLUID

Recommended fluids are: Chevron Oil Company Aviation Hydraulic Fluid A, Texaco Inc. Aircraft BB Hydraulic Oil,




Figure 7
Maintenance check points.

NOTE: Arrow indicates direction of pull for checking trip latch load (see Figure 11 for detail).

Shell Oil Company Aeroshell Fluid #4, Exxon Company Univis J-43.

Cleanliness is the best assurance of trouble-free operation. When performing these routine maintenance steps, if the equipment is out of adjustment, refer to the corresponding Adjustments section; if a part must be replaced, refer to the corresponding Parts Replacement section.

Following is the procedure for checking the hydraulic fluid level in sump.

1. Check level with closing spring discharged.
2. Dip stick connected to fill hole plug indicates fluid level.
3. An empty hydraulic system requires approximately 1-1/2 pints of fluid to fill sump.
4. Add one of the recommended hydraulic fluids through the fill hole to reach the proper level.

AUXILIARY SWITCH

1. Refer to the auxiliary switch manufacturer's instruction book that accompanies the breaker.

CLOSE COIL

WARNING

To inspect the close coil, the breaker must be OPEN and the closing spring DISCHARGED. Keep fingers and loose objects away from the closing spring and linkage.

1. Insure that the breaker is open and closing spring discharged.
2. Manually move the close latch to the set position by inserting a screwdriver through the opening in the operating mechanism frame and pulling the close latch to the set position (Figure 9).
3. With the close latch in the set position (Figure 9), the close coil armature air gap should measure .060 inches (1.52 mm).
4. If the close coil armature air gap requires adjustment, see close coil in the Adjustments section.

CLOSE COIL SWITCH, MOTOR CUTOFF SWITCH

1. Check for cracked switches or loose wires.

2. Refer to the wiring diagram and test the circuit to make sure the switches function properly when the switch buttons are depressed by the actuating arm on the valve block. The wiring diagram number is stamped on the nameplate.

NOTE: If an adjustment is made to obtain the correct close coil armature air gap, check the pressure-release valve, close coil switch and motor cutoff switch for proper operation in accordance with the Adjustments section.

TRIP COIL

WARNING

To inspect the trip coil, the breaker must be **CLOSED** and the closing spring **DISCHARGED**. Keep fingers and loose objects away from springs and associated linkage.

1. Close the breaker.
2. With the closing spring discharged and the trip latch set, measure the trip latch armature air gap (Figure 7).
3. Air gap should be .060 inch (1.52 mm).
4. If necessary adjust to this dimension in accordance with the Adjustments section.

TRIP LATCH

1. With the breaker open, charge the closing spring and check that the trip latch resets.
2. Close the breaker.
3. Trip the breaker and observe the trip latch action.
 - A. The trip latch will disengage allowing the linkage to collapse and the breaker to open.
 - B. The linkage will immediately reset on the trip latch, provided the closing spring is recharged.
4. The trip latch should function with a quick positive action.
5. If the trip latch does not function properly, measure the latch load and reset values and adjust as necessary in accordance with the Adjustments section (Figure 11).

OPENING BUFFER

Check that there is no fluid leakage.

NOTE: Normally, the opening buffer will not require adjustment. However, to insure that the drive linkage can function properly, the drive block must clear the belleville washer as shown in Figure 11. Refer to opening buffer in the Adjustments section if drive linkage does not function properly.

MOTOR

Since the motor is sealed, no maintenance should be required other than checking that the mounting bolts are tight and listening for excessive noise or bearing rumble.




Figure 8
Handpump used to manually charge closing spring.

Check motor mounting bolts for tightness. See Motor, in the Parts Replacement section if motor must be replaced.

HANDPUMP

1. Insert the handpump handle (furnished with the breaker) into the socket.
 2. Pump approximately ten to twelve strokes to charge the closing spring.
 - A. When the closing spring is charged, loss of pressure will be felt in the pumping operation.
 - B. If no pressure loss is felt, refer to Pressure-Release Valve in the Adjustments section.
- NOTE: The handpump can be used to charge the closing spring in the event of a loss of control power.
3. Check that the close latch is holding the close latch roller.

DUMP VALVE

Dump valve is factory set and will not require adjustment.

AUXILIARY DEVICES

Make sure all auxiliary devices are clean. If it is necessary to replace an auxiliary device, refer to auxiliary devices in the Parts Replacement section.

INTERIOR AND EXTERIOR CABINET SURFACES

Clean all internal and external cabinet surfaces.

NOTE: An industrial vacuum cleaner is recommended.

1. Using clean, lint-free rags wipe down all surfaces.
2. Check the interior and the exterior of the cabinet for

evidence of corrosion caused by leakage, moist air, or heater malfunction.

- A. Eliminate the cause of such corrosion if it exists. Correct this condition before proceeding to the next maintenance step.
- B. Make sure all electrical connections are tight.
- C. Make sure all fasteners are tight.
- D. Retouch painted surfaces where necessary for appearance and complete protection.

ADJUSTMENTS

WARNING

Deenergize the circuit breaker before making any adjustments on the MO-1 operating mechanism or the breaker. Unless stated otherwise in the procedure, all adjustments should be performed with the breaker open and the closing spring discharged. Contact position indicator must read **OPEN**. Closing spring position indicator must read **DISCHARGED**.

Observe all safety precautions in the vacuum circuit breaker instructions as well as those throughout these instructions when making adjustments. Although the Type MO-1 operator was designed with the safety of operating personnel foremost in mind, the mechanical characteristics of the operating mechanism and breaker, along with the necessary activities of operating personnel, make cautious work habits essential.




Figure 9

Close coil armature air gap.

NOTE: With closing spring discharged, insert screwdriver and pull close latch to set position.

CLOSE COIL

1. Check that the breaker is in the open position and the closing spring discharged.
2. Manually set the close latch roller to the set position as shown in Figure 9.

NOTE: Insert a screwdriver through the opening in the operating mechanism frame and pull the close latch to the set position.

3. Measure the close coil armature air gap.
4. Set the gap to .060 inch (1.52 mm) by using close coil armature adjusting screw.

NOTE: Once an adjustment is made, to obtain the correct close coil armature air gap, the pressure-release valve, close coil switch, and motor cutoff switch must be checked for proper operation.

PRESSURE-RELEASE VALVE, CLOSE COIL SWITCH, AND MOTOR CUTOFF SWITCH

1. With a .135 inch (3.43 mm) shim in the close coil armature air gap, the pressure-release valve adjusting nut should rest on the raised surface of the pressure-release valve operating arm – but not raise the pressure-release valve stem. Adjust as required.
2. Also, with a .135 inch (3.43 mm) shim in the close coil armature air gap, both the close coil switch and the motor cutoff switch should operate.
3. If the switches do not operate, adjust with the setscrews on the actuating arm (contact operation can either be determined audibly or by a continuity check).

NOTE: If adjustment is made to the close coil and motor cutoff switches, recheck the positive stop of the pressure-release valve operating arm against the raised surface of the valve block. Final adjustment should produce following results:

- .060 inch (1.52 mm) close coil armature air gap, pressure-release valve opens.
- .135 inch (3.43 mm) close coil armature air gap, close coil switch and motor cutoff switches operate.

See Figure 7 for close coil location reference and Figure 10 for detail.

TRIP LATCH

NOTE: The *latch load* is the pulling force required to move the trip roller in the trip latch. The force at which the trip roller returns to its original position is the *reset force*. Since this movement is very slight, be sure to observe carefully.

To measure trip latch load and reset values:

1. Close the breaker and wait for the closing spring to recharge.
2. As demonstrated in Figures 7 and 11, hook a metal strap or wire around the trip pin, bring it out the rear of the mechanism compartment, and attach a spring scale




Figure 10

Adjustment; high pressure-release valve, close coil switch, and motor cutoff switch.

which will measure from 10 to 100 lbs. (45 to 450 newtons).

3. Slowly pull on the scale until a release of the roller is observed—*latch load*—and record this value.
4. Slowly relax while pulling on the scale until roller returns—*reset*—record this value.
5. The latch load value should be between 50 and 75 lbs. (222.4 and 333.6 newtons). The minimum latch reset value should be 15 lbs. (66.7 newtons).
6. Measure and record three sets of latch load and reset values; between each set of measurements remove the strap and trip open then reclose the breaker.
7. Adjust the trip latch with the breaker closed, and the closing spring charged by turning the 5/8-inch adjustment bolt clockwise to increase the reset load and counterclockwise to decrease it.

NOTE: Latch load will increase approximately 2-1/2 lb. (11 newtons) per flat, when turned clockwise, and decrease 2-1/2 lb. (11 newtons) per flat when turned counterclockwise.

8. Check for proper adjustment by again taking latch-load and reset measurements.

TRIP COIL ARMATURE AIR GAP

WARNING

While adjusting the trip coil, the opening and closing springs will discharge at high speed. Keep fingers and foreign objects away from the springs and associated linkage.

1. The trip coil armature air gap should be .060 inches (1.52 mm) (Figure 7).
2. If adjustment is required:
 - A. Loosen lock nut on armature.
 - B. With pliers, turn knurled machine screw until .060 inch (1.52 mm) air gap is attained.
 - C. Retighten locknut.

NOTE: With the trip linkage set, check that the trip link does not hit the head of the stop bolt mounted in the mechanism frame. Maintain a 1/32-inch (.79 mm) gap between the stop bolt and the trip link by adjusting the stop bolt as needed.

OPENING BUFFER

To insure the drive linkage can function properly, the factory setting of 1/32 to 1/16-inch (.79 to 1.58 mm) gap must be maintained between the drive block and the belleville washer with the breaker in the open position, and the closing spring charged.




Figure 11
Trip latch adjustment.

1. Metal strap or wire hooked around trip pin.
2. Spring scale — (10 to 100 lbs.) (45 to 450 newtons).
3. Trip pin.
4. Trip latch roller.
5. 5/8" trip latch adjustment bolt.
6. Drive block.
7. Trip link.
8. Belleville washer.

1. If the trip linkage does not set, adjust for 1/32 to 1/16-inch (.79 to 1.58 mm) clearance between the drive block and belleville washer by adjusting the opening buffer (Figure 7).
2. To increase the clearance, the opening buffer is adjusted by turning clockwise.

3. The measurement must be made from the rear of the mechanism compartment. Measure from the top of the belleville washer to the drive block (Figure 11).

TRIP LATCH SWITCH

1. Check to see that plunger on trip latch switch clicks when trip linkage is set on trip latch (Figure 7).
2. If switch does not operate when trip linkage is set, bend the trip latch switch actuating arm to permit proper operation.

DUMP VALVE

The dump valve is factory set and requires no adjustment.

PARTS REPLACEMENT

SAFETY PRECAUTION

The vacuum breaker on which the MO-1 operating mechanism is mounted must be removed from service prior to replacing operating mechanism parts. Proper parts replacement procedures require that the breaker be open, closing spring discharged and the auxiliary electrical system be deenergized.

CLOSE COIL

1. Disconnect the close coil wiring from the terminal block.
2. Remove the bolts and washers which mount the close coil to the mechanism.
3. Remove the coil.
4. Mount replacement coil on the mechanism frame, with the bolts and washers.
5. Check following items per Adjustment section:
 - A. Close coil.
 - B. Pressure-release valve.
 - C. Close coil and motor cutoff switches.

TRIP COIL

1. Disconnect the trip coil wiring from the terminal block, then use same procedure used to replace the close coil.
2. Check following items per Adjustment section:
 - A. Trip coil.
 - B. Trip latch switch.
 - C. Linkage.

AUXILIARY SWITCH

NOTE: Follow the switch manufacturer's instructions for internal adjustments to switch.

1. Remove auxiliary switch wiring at the switch.
2. Remove cotter pin, washer, and operating link from switch.
3. Remove bolts securing switch mounting bracket to the breaker frame; then remove bolts securing switch to mounting bracket.
4. Note the position of the contacts and the remaining linkage on the switch:
 - A. Looking from the linkage end, the linkage should be at an approximate 7:30 o'clock position and typically a contacts 1 and 2 should be open, b contacts 3 and 4 should be closed, etc.
 - B. Contact for contact the replacement switch must operate the same as the old switch (discounting a broken stage in the old switch).
 - C. Operate the old switch counterclockwise 90° to approximately a 4:30 o'clock position, and observe the action of the contacts.
5. Remove the remaining linkage from the old switch shaft.
6. Install operating arm on shaft of new switch.
7. Bolt new switch to mounting bracket.
8. Secure mounting bracket to breaker frame.
9. Replace switch wiring.
10. Replace operating link, washer, and cotter pin in switch linkage.

MOTOR

1. Disconnect wires.
2. Remove two mounting bolts.
3. Put replacement motor in position.
4. Connect wires.
5. Replace and tighten mounting bolts.

See Troubleshooting Chart, page 12.

TROUBLESHOOTING

FAILURE TO CHARGE THE CLOSING SPRING

POSSIBLE CAUSE	SOLUTION
<ol style="list-style-type: none"> 1. Motor does not run <ol style="list-style-type: none"> A. No supply voltage to motor B. Charging motor cutoff switch 2. Motor continues to run <ol style="list-style-type: none"> A. Insufficient oil to sump B. Pressure release valve open C. Charging motor cutoff switch 	<ol style="list-style-type: none"> A. Check fuses, wiring, secondary contact B. Check adjustment A. Fill sump as prescribed B. Check adjustment C. Check adjustment

FAILURE OF BREAKER TO CLOSE

POSSIBLE CAUSE	SOLUTION
<ol style="list-style-type: none"> 1. Closing spring not charged 2. No supply voltage to closing coil 3. Closing coil switch 4. Open circuited closing coil 5. Auxiliary switch 6. Linkage doesn't reset 7. Trip latch switch 	<ol style="list-style-type: none"> 1. Charge spring 2. Check fuses, wiring, secondary contacts 3. Check adjustment 4. Replace coil 5. Inspect auxiliary switch 6. Adjust closing buffer 7. Check adjustment

FAILURE OF BREAKER TO OPEN

POSSIBLE CAUSE	SOLUTION
<ol style="list-style-type: none"> 1. Breaker not closed 2. No supply voltage to trip coil 3. Auxiliary switch 4. Open circuited trip coil 	<ol style="list-style-type: none"> 1. Close breaker 2. Check wiring secondary contacts 3. Inspect auxiliary switch 4. Replace coil

Power Circuit Breakers

Type OE Bushing Current Transformers

Installation and Maintenance Instruction

S290-80-2
Service Information

GENERAL

Service Information S290-80-2 pertains specifically to McGraw-Edison Type OE bushing current transformers (Figure 1) for use in relay operation. Provided only a general indication of values is satisfactory, Type OE bushing current transformers are also suitable for use with indicating meters or for nonrevenue metering purposes.

Type OE bushing current transformers conform to both NEMA and ANSI standards for relaying accuracy current transformers.

When installing or performing maintenance work on a Type OE bushing current transformer, the latest revision of the oil circuit breaker instructions—copy of which accompanies each breaker—must be followed.

SHIPPING

Except when ordered as replacement parts, Type OE bushing current transformers are shipped installed in the equipment for which they are required. When supplied separately, bushing current transformers are crated for shipping.

INITIAL INSPECTION

Immediately upon receipt—preferably before unloading—thoroughly inspect the current transformer for evidence of rough handling or damage in transit. Should there be evidence of rough handling or damage in transit, notify—and file a claim with—the carrier at once. Also notify McGraw-Edison Power Systems Division, Canonsburg, Pa. 15317.

IDENTIFICATION

Amp Ratings

McGraw-Edison Type OE bushing current transformers are identified by amp rating: an OE-6 transformer is rated at 600 amps; an OE-12 transformer is rated at 1200 amps, etc.

Leads

Refer to the wiring diagram and ratio tables that accompany the circuit breaker for winding and lead data for the specific equipment.

Standard NEMA markings are used to identify secondary leads and polarity. Leads are marked X1, X2, X3, X4, and X5. When two current transformers are used around a single entrance bushing, the leads from the second current transformer are lettered Y1, Y2, etc., at the terminal block—although the actual leads on the transformers have the X markings. Polarity for current transformers is indicated by a white paint mark on the X1 lead. The top of the current transformer is indicated by a white mark or an H1 mark. This mark (white or H1) must be placed upward when the current transformer is installed.

NOTE: If the X1 lead is not used as a tap, the lead that is numerically closest to X1 will have the same polarity as the X1 lead.

HANDLING

When handling a bushing current transformer, take special care to prevent deforming its shape. Deformation could result in an increase in excitation current and a reduction in ratio accuracy.

STORAGE

If a bushing current transformer is not to be placed in service immediately upon receipt, it must be stored indoors in a dry, protected location. Under no circumstances should a bushing current transformer be left outdoors, exposed to the weather.




Figure 1.
Typical Type OE bushing current transformer.

These instructions do not claim to cover all details or variations in the equipment, procedure, or process described, nor to provide directions for meeting every possible contingency during installation, operation, or maintenance. When additional information is desired to satisfy a problem not covered sufficiently for the user's purpose, please contact your McGraw-Edison Power Systems Group sales engineer.

INSTALLATION

To replace a bushing current transformer, refer to—and follow—applicable portions of the circuit breaker instructions.

For bushing current transformer connections, refer to the wiring diagram supplied with the equipment on which the current transformer is installed. For transformer ratios, refer to the nameplate located near the transformer terminal block.

Before installing a bushing current transformer:

1. Check to be sure the current transformer is free from moisture.
2. If moisture is present, heat the current transformer with dry, warm air—not to exceed 150 F (66 C)—until all traces of moisture are gone.

CAUTION:

Type OE bushing current transformers are wound for subtractive polarity (Figure 2). To retain this polarity, it is imperative that the current transformer be installed with the polarity mark (the white mark or the H1 mark) upward.

WIRING AND CONNECTIONS

Wiring to the control cabinet terminal block is completed at the factory. If bushing current transformers are installed in the field, connections to the terminal blocks and from the terminal blocks to the relays or the instruments of the burden circuit must be made in such a manner as to assure low resistance.

SAFETY PRECAUTION:

At no time should a bushing current transformer operate with an open circuit. The current transformer must either be connected to a burden or be short-circuited.

SHORT CIRCUITING A BUSHING CURRENT TRANSFORMER AT THE TERMINAL BLOCK

The terminal blocks are provided with shorting screws for short circuiting the current transformer when no burden is connected (Figure 3).

To disconnect the burden and assure that the bushing current transformer circuit is not opened:

1. Short circuit the current transformer by inserting the shorting screws—

stored in the holes in the ends of each terminal block—in the terminals that are connected to the current transformer.

2. Remove the burden.

To connect the burden:

1. Make sure the burden circuit is closed.
2. Connect the leads to the terminal blocks.
3. Remove the shorting screws.

NOTE: Immediately upon removing the shorting screws, store them in the holes in the ends of each terminal block.

It is recommended that the entire bushing current transformer winding be short circuited even though only part of it is used to supply the burden. Therefore, although the bushing current transformer may be connected by the X1 and the X3 taps:

4. Firmly insert the shorting screws into the holes adjacent to the X1 and the X5 terminals.

Do not remove the shorting screws until the burden is connected.

Insert the shorting screws before the burden is disconnected.

NOTE: The terminal blocks also contain a ground terminal that is usually connected to a grounded portion of the cabinet or directly to a ground grid.




Figure 2.
Typical transformer arrangement and polarity.

INSULATION TEST

Bushing current transformers are not subjected to line potential, but they are subjected to a moderate, induced voltage. After installation, each bushing current transformer should be subjected to a one-minute potential test at 2500 volts rms between the shorted secondary winding and ground, including leads.

NOTE: If a potential test is conducted as a routine check, it should be made at a reduced voltage of approximately 1500 volts rms.

INSULATION CHECK

After a bushing current transformer has been installed and all connections have been made, it should be checked for:

1. Accidental ground.
2. Proper connections.
3. Correct polarity.

To check the current transformer for accidental grounding or low-leakage resistance, use a 500 or 1000 volt megger:

1. Short circuit the terminal blocks and megger the resistance between the secondary winding and the circuit breaker frame. This resistance should have a value in megohm range.
2. If the resistance is unusually low, the bushing current transformer and secondary leads should be inspected for accidental grounding or moisture.

MAINTENANCE

Type OE bushing current transformers generally do not require attention beyond an occasional check to make sure that leads have not been damaged or shorted and that connections are tight.

SAFETY PRECAUTION:

If the secondary of the bushing current transformer has been accidentally opened when line current is flowing in the primary (entrance bushing), a dangerous, excessive peak voltage that could damage the insulation may develop in the secondary. A ratio test should be made on the installed bushing current transformer if symptoms indicate a short-circuit condition in the bushing current transformer winding.




Figure 3.
Short-circuit terminal blocks.

$$\begin{matrix} X2 = 100:5 \\ X3 = 1000:5 \end{matrix}$$

$$\begin{matrix} X2 = 1000:5 \\ X5 = 1000:5 \end{matrix}$$

$$\begin{matrix} X1 = 200:5 \\ X2 = 200:5 \end{matrix}$$

$$\begin{matrix} X1 = 1200:5 \\ X5 = 1200:5 \end{matrix}$$

$$\begin{matrix} X1 = 300:5 \\ X3 = 300:5 \end{matrix}$$

$$\begin{matrix} X4 = 400:5 \\ X5 = 400:5 \end{matrix}$$

$$\begin{matrix} X3 = 500:5 \\ X4 = 500:5 \end{matrix}$$

$$\begin{matrix} X2 = 600:5 \\ X4 = 600:5 \end{matrix}$$

$$\begin{matrix} X1 = 800:5 \\ X4 = 800:5 \end{matrix}$$

$$\begin{matrix} X3 = 900:5 \\ X5 = 900:5 \end{matrix}$$