



**DCBU**

**DISTRIBUTION AND CONTROL BUSINESS UNIT**

# **Switchgear Components Handbook**

## **Prices**



## Switchgear Components Handbook

| Style Number | Description                                             | List Price | Style Number | Description                                                         | List Price |
|--------------|---------------------------------------------------------|------------|--------------|---------------------------------------------------------------------|------------|
| 139D693G01   | DSL-206 Bkr Mounting Pan                                | \$ 731 ①   | 449D480G13   | DS840 Kirk Key Interlock Provision, 1 Key, One-High                 | \$ 260     |
| 139D693G05   | DSL-416 Bkr Mounting Pan                                | 731 ①      | 449D480G17   | DS206-420 Kirk Key Interlock Provision, Substructure or Erector Set | 260        |
| 140D294H01   | 206/420 Bus Boot W/O CT                                 | 9          | 449D480G18   | DS632-840 Kirk Key Interlock Provision, Substructure or Erector Set | 260        |
| 140D294H02   | 206/420 Bus Boot W CT                                   | 9          | 449D622G09   | DS Auxiliary Switch Cover                                           | 28         |
| 140D768H01   | DS-632 Bus Boot W CT                                    | 15         | 567F384G01   | DS 3200A One Piece Contact Mtg. Plate                               | 185        |
| 140D769H01   | DS-632 Bus Boot W/O CT                                  | 18         | 567F908G01   | DS 600/2000A Contact Mtg. Plate                                     | \$ 92 ①    |
| 151D010G01   | DS-632 Fuse Truck Mounting Pan                          | 585 ①      | 567F910G01   | DS 3200A Contact Mtg. Plate                                         | 92 ①       |
| 151D372H01   | DS-840SEC Cont Mtg Bkt                                  | 62         | 567F973G03   | DS 840 Bkr & Fuse Truck Mtg. Pan                                    | 926 ①      |
| 151D544G01   | DS-206 Bkr Mounting Pan                                 | 555 ①      | 588C729G02   | DS Sec. Disconnecting Cover                                         | 18         |
| 151D544G03   | DS-416 Bkr Mounting Pan                                 | 555 ①      | 588C734G01   | DS 840 4000A Sensor                                                 | 560        |
| 151D544G05   | DS-632 Bkr Mounting Pan                                 | 566 ①      | 588C772H01   | DS 840 Spacer Plate                                                 | 108 ①      |
| 151D544G13   | DS-420 Bkr Mounting Pan                                 | 597 ①      | 588C943G01   | DS Bkr Seismic Positioner, DS206-DS420                              | 196        |
| 151D995G01   | DS 206/420 100A Sensor                                  | 250        | 588C943G02   | DS Bkr Seismic Positioner, DS632                                    | 196        |
| 151D995G02   | DS 206/420 200A Sensor                                  | 228        | 588C943G03   | DS Bkr Seismic Positioner, DS840                                    | 196        |
| 151D995G03   | DS 206/420 300A Sensor                                  | 215        | 588C944H01   | DS Rear Bus Insulation                                              | 16 ①       |
| 151D995G04   | DS 206/420 400A Sensor                                  | 212        | 588C948H01   | DS Rear Stabs-632                                                   | 47 ①       |
| 151D995G06   | DS 206/420 600A Sensor                                  | 190        | 590C454H01   | DS Runback Supt-1.75 x 5 Bus                                        | 357        |
| 151D995G08   | DS 206/420 800A Sensor                                  | 178        | 590C808G01   | DS Stationary 8 PT Sec Cont                                         | 75         |
| 151D995G12   | DS 206/420 1200A Sensor                                 | 178        | 591C357G01   | DS Riser Support                                                    | 38         |
| 151D995G15   | DS 206/420 150A Sensor                                  | 240        | 591C498G06   | DS Moving 8 PT Sec Cont                                             | 69         |
| 151D995G16   | DS 206/420 1600A Sensor                                 | 190        | 591C756G02   | Order S.N. 591C756G01 & 687C206G02                                  |            |
| 151D995G20   | DS 420 2000A Sensor                                     | 200        | 6435C06G01   | Shutters for DS 206-420, 1 Piece Mtg. Plate                         | 450        |
| 151D995G23   | DS 632 2400A Neutral Sensor                             | 317        | 6435C06G02   | Shutters for DSL 206 and DSL 416, 1 Piece Mtg. Plate                | 450        |
| 151D995G24   | DS 632 2400A Phase Sensor                               | 405        | 6435C10G01   | Shutters for DS 632                                                 | 500        |
| 151D995G31   | DS 632 3200A Neutral Sensor                             | 380        | 6435C11G01   | Shutters for DS 206-420, 2 Piece Mtg. Plate                         | 450        |
| 151D995G32   | DS 632 3200A Phase Sensor                               | 426        | 6435C17G01   | Shutters for DS 840                                                 | 575        |
| 19D888H02    | DS Rear Bus Insul Mounting Bkt                          | 5          | 6727D63H20   | Portable Lift Truck                                                 | 3500       |
| 349A364H01   | Handle Latch                                            | 7          | 690C950H01   | DS Bkr Arc Shield DS206-632                                         | 35 ①       |
| 349A366H01   | Handle Spacer for Standard Door                         | 6          | 699B716H01   | DS 840 Riser Stab                                                   | 200        |
| 349A669G01   | DS Manual Bkr Charging Handle                           | 20         | 749A474H01   | Trip Push Plate                                                     | 4 ①        |
| 349A669G03   | DS Electric Bkr Charging Handle                         | 24         | 749A475H01   | DS Door Trip Sticker                                                | 1 ①        |
| 349A944H01   | DS 206/416 3 In Riser Stab                              | 112 ①      | 788A534H01   | DS Trip Button Hinge Bracket                                        | 5 ①        |
| 3582A07H01   | DS Spacer Plate 632                                     | 43 ①       | 788A562H01   | DS Bkr Mtg Pan Supt-840                                             | 4 ①        |
| 3587A04H01   | DS 840 Cell SW Mounting Kit                             | 9          | 794A170G01   | See 436B080G01                                                      |            |
| 3703A85G01   | DS 206-420 Sensor Mounting Kit                          | 28         | 794A638H03   | Breaker Mtg. Pan Support-All But DS840                              | 4 ①        |
| 3703A85G02   | DS 632 Sensor Mounting Kit                              | 28         | 794A965H01   | Sensor Spacer                                                       | 3          |
| 3703A85G03   | DS 840 Sensor Mounting Kit                              | 28         | 795A386H03   | DS Arc Shield-840                                                   | 64 ①       |
| 436B056H01   | DS Rear Stabs-416 & 420                                 | 24 ①       | 802B335G02   | Travelling Lifter Crank                                             | 210        |
| 436B057H01   | DS Rear Stabs-206                                       | 12 ①       | 809A476H01   | DS Riser Stabs-206, 416 & 420                                       | 112 ①      |
| 436B080G01   | DS-206 50A Sensor                                       | 520        | 809A482H01   | DS Riser Stabs-632                                                  | 336 ①      |
| 436B112H01   | DS-4000A Contact Mounting Plate                         | 104 ①      | 809A493H03   | DS Spacer Plate-206, 416 & 420                                      | 35 ①       |
| 436B451H01   | Handle for Standard Door                                | 21         | 809A495H01   | DS-632 B Metering CT Mtg. Bkt                                       | 37         |
| 436B657G01   | DS Moving Sec Cont Mounting Bkt                         | 50         | 809A769H01   | DS Spacer Plate-840                                                 | 11 ①       |
| 436B696G01   | DS Bkr Levering in Crnk                                 | 12         | 8965D31G01   | Monorail Lifter For DS 206-632                                      | 2300       |
| 449D371H01   | DS Runback Supt-.75 x 6 Bus                             | 140        | 8965D31G02   | Monorail Lifter For DS 206-840                                      | 2600       |
| 449D395G01   | DS 1 Piece Mounting Plate                               | 80 ①       | 9562D43G01   | Lifting Yoke For DS & DSL 206-632                                   | 110        |
| 449D465H01   | DS Runback Supt-.5 x 3 Bus                              | 72         | 9562D43G04   | Lifting Yoke For DS & DSL 206-840                                   | 170        |
| 449D465H02   | DS Runback Supt-.5 x 1.5 Bus                            | 72         |              |                                                                     |            |
| 449D480G11   | DS206-420 Kirk Key Interlock Provision, 1 Key, One-High | 260        |              |                                                                     |            |
| 449D480G12   | DS632 Kirk Key Interlock Provision, 1 Key, One-High     | 260        |              |                                                                     |            |

① Denotes DS Erector Set Part.



## Switchgear Components Handbook

| Style Number                      | Description                                   | List Price |
|-----------------------------------|-----------------------------------------------|------------|
| <b>DS Field Modification Kits</b> |                                               |            |
| 3752A02G04                        | DS/DSL 206-632, 125Vdc Shunt Trip             | \$ 425     |
| 3752A02G06                        | DS/DSL 206-632, 120Vac Shunt Trip             | 425        |
| 3752A03G02                        | DS/DSL 206-632, 125 Vdc Spring Release        | 425        |
| 3752A03G04                        | DS/DSL 206-632, 120 Vac Spring Release        | 425        |
| 3752A04G01                        | DS/DSL 206-632 Man. OC Trip Switch 2 Contacts | 425        |
| 3752A05G01                        | DS/DSL 206-632 UV Instantaneous 120 Vac       | 425        |
| 3752A05G06                        | DS/DSL 206-632 UV Instantaneous 125 Vdc       | 450        |
| 3752A06G01                        | DS/DSL 206-632 UV Time Delay 120 Vac          | 670        |
| 3752A06G06                        | DS/DSL 206-632 UV Time Delay 125 Vdc          | 670        |
| 591C380G31                        | DS First Auxiliary Switch                     | 330        |
| 690C748G01                        | DS Second or Third Auxiliary Switch           | 330        |

### Terms and Conditions

For Terms and Conditions of Sale, Refer to Selling Policy 50-000.

Volume 1 is for use by OEM's incorporating Westinghouse breakers into their product. Quantity of parts purchased must correlate to quantity of breakers purchased from Westinghouse. Renewal parts price schedules apply for all other OEM situations and customer classifications.

### Low Voltage

DS Accessories, Erector Set Parts, and Field Modification Kits.

### Multiplier

OEM Multiplier for Volume I Prices — **.40 Mult.**

### Note:

Kits do not include secondary contact blocks nor limit switches. Contact Commercial Support Team for other control voltages and contact arrangements.

**Westinghouse Electric Corporation**  
**Distribution and Control Business Unit**  
**Electrical Components Division**  
**Pittsburgh, PA 15220**

**MB 3282-1D File 33-000**

**Printed in U.S.A.**